

HYmini Mobile Phone Adaptors List v.7

Please see below for mobile phone adaptors that are included in the HYmini Basic/Deluxe Package and their compatible models.

Mobile Phone	Item No./ Market	Supported Models
--------------	------------------	------------------



TP_NO01
small round



NOKIA

Mobile Phones :

1200/ 1208/ 1650/ 2135/ 2310/ 2630/ 2760/ 2865i/ 3109
 Classic/ 3110 Classic/ 3152/ 3155/ 3155i/ 3250/ 3250 Xpress
 Music/ 3500 Classic/ 5070/ 5200/ 5300 XpressMusic/ 5310
 XpressMusic/ 5500 Sport/ 5610 XpressMusic/ 6070/ 6080/
 6085/ 6086/ 6101/ 6102/ 6102i/ 6103/ 6111/ 6120 Classic/ 6121
 Classic/ 6125/ 6126/ 6131/ 6131 NFC/ 6133/ 6136/ 6151/ 6152/
 6155/ 6155i/ 6165i/ 6233/ 6233 Music Edition/ 6263/ 6265/
 6265i/ 6267/ 6268/ 6270/ 6275i/ 6280/ 6282/ 6288/ 6290/ 6300/
 6500 Slide/ 6555/ 7360/ 7370/ 7372/ 7373/ 7390/ 7500 Prism/
 770 Internet Tablet/ 8800 Sirocco Edition/ 8800 Sirocco Gold
 Edition/ E50/ E61/ E61i/ E62/ E65/ E90 Communicator/ N70/
 N70 Music Edition/ N71/ N72/ N73/ N73 Music Edition/ N75/
 N76/ N77/ N80/ N800 Internet Tablet/ N80ie/ N810 Internet
 Tablet/ N90/ N91/ N91 8GB/ N91 WCDMA/ N92/ N93/ N93i/
 N95

Other Devices :

BH-100/ BH-200/ BH-201/ BH-202/ BH-206/ BH-207/ BH-208/
 BH-300/ BH-301/ BH-301-LT/ BH-302/ BH-303/ BH-500/
 BH-501/ BH-600/ BH-700/ BH-700-BK/ BH-700-WH/ BH-701/
 BH-800/ BH-800-BK/ BH-800-WH/ BH-801/ BH-900/ HS-26W



TP_NO02 (TP_MT02)
Micro USB



1606/ 3606/ 6205/ 6500 Classic/ 7900/ 8600 Luna/ 8800/ N85

Motorola :

ic402/ ic502/ A780/ E770v/ E1070/ L2/ L6/ PEBL/ MOTOKRZR K1/ MOTOKRZR K1m/ MOTORAZR V3r/ MOTORAZR V3t/ MOTORAZR V3xx/ red MOTORAZR V3m/ RAZR V3/ RAZR V3i/ RAZR V3x/MOTORIZR Z3/ SLVR L7c/ V360/ V360v/ SLVR/ V190/ V195/ V197/ V235/ V323/ V323i/ V325/ V325i/ V360/ V360v/ V361/ V365/ W315/ Motofone F3

**TP_MT01**

Mini-USB

**Blackberry :**

6210/ 6220/ 6230/ 6280/ 6510/ 7100g/ 7100i/ 7100r/ 7100t/ 7100v/ 7100x/ 7105t/ 7130e/ 7210/ 7230/ 7250/ 7270/ 7280/ 7290/ 7510/ 7520/ 8100 (Pearl)/ 8700c/ 8700f/ 8700g/ 8703e

iRiver™ :

T10 series/T30 series/PMP-100 series/PMC-100 series/H300 Series/H140/H120/H100/iGP-100/iFP-1000 series/iFP-900 series/iFP-800 series/iFP-700 series/iFP-300 series/N10

Garmin GPS :

Forerunner 205/Forerunner 203/Forerunner 301/Edge 205/Edge 305

TomTom**T Mobile :**

G1 phone (Google)

Digital Camera :

This connector will work with Digital Cameras that accept charge via their Mini-USB port.

MOTOROLA

Micro-USB adaptor for use with a wide range of devices

Blackberry :

Curve 8900/ Pearl Flip 8220/ Storm 9530

LG :

AX155/ AX300/ AX830/ Glimmer UX830/ Incite CT810/ KEYBO 9100/ KF300/ LG830 Spyder/ LX400/ Lotus LX600/ Reveal LG600/ Rhythm AX585/ Slyde M540/ Swift AX500/ UX300/ UX585/ VX8560 Chocolate 3/ VX 8610 Decoy/ VX9700 Dare/ Vantage 830/ Wine 280/ enV2 VX9100

**TP_MT02 (TP_NO02)**

Micro USB

**Motorola :**

AURA/ Adventure V750/ Hint QA30/ Krave ZN4/ MOTO Q9h/ MOTO Qglobal/ RAZR VE20/ RAZR2 V8/ V9/ V9m/ V9x/ ROKR E8 U9/ Rapture VU30/ Renegade V950/ Z6c world edition/ Z9. Zine ZN5/ I576/ I776

Palm :

Treo Pro

Samsung :

Highnote SPH-M630/ Rant SPH-M540/ SGH-G810/ SPH-M220/
SPH-M320

Sanyo :

Katana Eclipse/Eclipse X/ Katana LX/ PRO-200/ PRO-700/ S1

**SONY
ERICSSON**



TP_SE01



D750i/J100a/J100c/J100i/J220a/J220c/J220i/J230c/J230i/K310
a/K310c/K310i/K320i/K510a/K510c/K510i/K610i/K610im/K750c
/K750i/K758c/K790a/K790c/K790i/K800i/M600i/M608c/P990i/V
630i/W300c/W300i/W550c/W550i/W600c/W600i/W700c/W700i
/W710c/W710i/W800i/W810c/W810i/W830i/W850i/W900c/W90
0i/W950i/W958c/Z520a/Z520c/Z520i/Z525a/Z525i/Z530c/Z530i
/Z550a/Z550c/Z550i/Z558c/Z558i/Z610i/Z710c/Z710i/J220i/K61
8i/M600i/W800c/W830c



TP_SM02

New Samsung Model



SPH-M610/SCH-U420/SGH-D807/SGH-D900/SGH-I607/SGH-
T519/SGH-T509/SGH-T809/SGH-T629/SGH-D520/SGH-D800/
SGH-D830/SGH-D807/SGH-E250/SGH-E550/SGH-780/SGH-
E870/SGH-E900/SGH-J600/SGH-P300/SGH-T509/SGH-T809/
SGH-V804/SGH-X820/SGH-X830/SGH-Z150/SGH-Z400/SGH-
Z510/SGH-Z540

SAMSUNG



TP_SM01

Old Samsung Model



4010/ 4011/ 4015/ 4020/ 4050/ 7050/ A7110/ B2050/ C1200/
C1300/ C1500/ C2000/ C2200/ C3300/ C3310/ C3320/ CE500/
CG300/ F2250/ F2400/ F7200/ F7250/ F9100/ F9200/ L1100/
L1150/ L1200/ L1400/ L5100/ P7200/ S5200/ U300/ U8110/
U8120/ U8130/ U8138/ U8150/ U8180/ U8290/ U8330/ U8360/
U8380/ U880/ U890



TP_LG02

LG Chocolate



Chocolate(460-S1-LGC)AX275/ AX8600/ CHOCOLATE/
CHOCOLATE CHERRY/ CHOCOLATE MINT/ CHOCOLATE
PINK/ CHOCOLATE WHITE/ CU515/ CU575/ CU720/ U970/
CU915/ CU920/ CU920 Vu-TV/VU EnV/ LG Rumor/ LX150/
LX260/ LX570/ Muziq Black/ Muziq Pink/ TRAX/ UX380/
VX10K/ VX10K VOYAGER/ VX8350/ VX8550 Black/ VX8550
Dark Blue/ VX8550 Dark Red/ VX8550 Metallic Black/ VX8600/
VX8700/ VX8800/ VX8800 VENUS/ VX9400/ KG800/ KG810/
KG320/ WAVE/ U970

LG



TP_LG01

Old LG Model



SCH-A210/ SCH-A310/ SCH-A399/ SCH-A475/ SCH-A505/
SCH-A509/ SCH-A530/ SCH-A539/ SCH-A563/ SCH-A564/
SCH-A570/ SCH-A591/ SCH-A592/ SCH-A595/ SCH-A599/
SCH-A610/ SCH-A650/ SCH-A670/ SCH-A795/ SCH-A809/
SCH-N181/ SCH-N181/ SCH-N182/ SCH-N191/ SCH-N195/
SCH-N288/ SCH-N330/SCH-N370/ SCH-N375/ SCH-U540/
SCH-X199/ SCH-X209/ SCH-X309/ SCH-X319/ SCH-X359/
SGH-A200/ SGH-A288/ SGH-A300/ SGH-A308/ SGH-A400/
SGH-A408/ SGH-A500/ SGH-A561/ SGH-A608/ SGH-A800/
SGH-C100/ SGH-C130/ SGH-C207/ SGH-C225/ SGH-C417/
SGH-D100/ SGH-D307/ SGH-D347/ SGH-D357/ SGH-D407/
SGH-D415/ SGH-D500/ SGH-D600/ SGH-D800/ SGH-E100/
SGH-E105/ SGH-E300/ SGH-E315/ SGH-E316/ SGH-E317/
SGH-E330/ SGH-E330N/ SGH-E350/ SGH-E335/ SGH-E370/
SGH-E400/ SGH-E600/ SGH-E630/ SGH-E635/ SGH-E700/
SGH-E710/ SGH-E715/ SGH-E760/ SGH-E770/ SGH-E800/
SGH-K528/SGH-N200/ SGH-N400/ SGH-N500/ SGH-N620/
SGH-N625/ SGH-N628/ SGH-P107/ SGH-P207/ SGH-P400/
SGH-P408/ SGH-P510/ SGH-P735/ SGH-Q100/ SGHQ200/
SGH-Q208/ SGH-Q300/ SGH-R200/ SGH-R208/ SGH-R210/
SGH-R210S/ SGH-R220/ SGH-R225/ SGH-R225M/
SGH-S100/ SGH-S200/ SGH-S208/ SGH-S300/ SGH-S300M/
SGH-S307/ SGH-S308/ SGH-S500/ SGH-T100/ SGH-T108/
SGH-T200/ SGH-T208/ SGH-T209/ SGH-T309/ SGH-T319/
SGH-T410/ SGH-T400/ SGH-T408/ SGH-T500/ SGH-T609/
SGH-T619/ SGH-T709/ SGH-T719/ SGH-V100/ SGH-V200/
SGH-V205/ SGH-V206/ SGH-X100/ SGH-X105/ SGH-X426/
SGH-X427/ SGH-X427M/ SGH-X450/ SGH-X460/ SGH-X475/

SGH-X480/ SGH-X495/ SGH-X497/ SGH-X507/ SGH-X600/
SGH-X640/ SGH-X660/ SPH-A420/ SPH-A580/ SPH-A640/
SPH-A900/ SPH-M500/ SPH-T100

DC / DC



TP_DC01

standard round /
DC to DC adaptor



HYmini miniSOLAR Panel

other 5V mobile devices

***Not compatible with old Nokia model**

Apple iPod / iPhone



TP_AP02

iPod / iPhone Adaptor v2



iPod nano 1st generation

iPod nano 2nd generation (aluminum casing)

iPod nano 3rd generation (video)

iPod 5th generation (video)

iPod classic

iPod touch

iPhone

*** Not compatible with following models**

iPod shuffle series

iPod mini series

iPod 1~4th generation

Nintendo DS



Nintendo DS,
Nintendo DSL

TP_ND01



Sony PSP



Sony PSP

TP_NO02



au



All au models



TP_AU01



SoftBank



All SoftBank models



TP_SB01

JP

DoCoMo




All DoCoMo models





TP_DO01

JP

Legend


 HYmini Deluxe Package sold through web shop for US region

 HYmini Basic Package sold through web shop for US region

 HYmini Basic Package distributed by Tango Group, UK

 UniRoss co-branded Bike Package in UK & EU,

 HYmini Deluxe Package distributed in Japan

 Sold separately in HYmini Online Shop.

Please Note: Some packages may contain different types of adaptors as specified by distributor contracts. Package content is subject to change without notice.

2009.08.05 rev.

Referenced Trademarks

- 1.iPod® is a registered trademark of Apple Inc. in the U.S.A. or other countries.
- 2.Nokia is a registered trademark of Nokia Corporation in the U.S.A. or other countries.
- 3.Sony Ericsson is a registered trademark of Sony Ericsson Mobile Com.AB in the U.S.A. or other countries.
- 4.Samsung is a registered trademark of SAMSUNG Corporation in the U.S.A. or other countries.
- 5.Motorola is a registered trademark of Motorola, Inc in the U.S.A. or other countries.
- 6.LG is a registered trademark of LG Electronics in the U.S.A. or other countries.
- 7.BlackBerry® is a registered trademark of Research In Motion in Canada or other countries.
- 8.Garmin® is a registered trademark of Garmin Ltd. in the U.S.A. or other countries.
- 9.iriver is a registered trademark of ReignCom Co., Ltd. in the U.S.A.or other countries.
- 10.Nintendo DS™ is a registered trademark of Nintendo Company,Inc. in the Japan or other countries.
- 11.PSP™ is a registered trademark of Sony Computer Entertainment Inc. in the U.S.A.or other countries.
- 12.au™ is a registered trademark of KDDI CORPORATION, in the Japan or other countries.
- 13.SoftBank™ is a registered trademark of SOFTBANK MOBILE Corp., in the Japan or other countries.
- 14.DoCoMo™ is a registered trademark of NTT DOCOMO, INC., in the Japan or other countries.